

YAESU 1900  
REPEATER MEMORY

In VFO mode select freq  
Press and hold 'SET' for 1 sec  
Rotate dial to 'SQL TYP' (49)  
Press "SET" then rotate dial to  
"TONE" (51)  
Press "SET" and rotate dial to  
"TONE FEQ" (52)  
Press "SET" and rotate dial to  
selected tone freq  
Press "SET" for 1 sec  
Within 5 seconds rotate dial  
to desired memory number  
Press "M/W" again to store

Ron Green KG6RLG

YAESU 1900  
SIMPLEX MEMORY

In VFO mode select freq  
Press and hold 'M/W' key 1 sec  
Within 5 seconds, rotate dial  
To desired memory number  
Press "M/W" key again  
POWER CHANGE  
Press "LOW" (A/N) key or  
Press "C" key on mic. Bargraph  
Under freq display indicates  
power setting  
DELETE FREQS  
Select freq, press and hold "D/MR"  
Key 1 sec, press "A/N (LOW)"  
Press PTT

t