

YAESU VX-7
SIMPLEX MEMORY

While in VFO enter freq.

Press "MON" key ½ second
Press "MON" again, press PTT

CHANGE POWER LEVEL

Press "MON" key then
Press "TX PO LK" key
Press "MON" again, then
press "TX PO LK" key
repeatedly to desired power level
Press PTT

KEYBOARD LOCK

To lock press "TX PO LK" key
2 seconds
To unlock press "TX PO LK" key
2 seconds

Ron Green KG6RLG

YAESU VX-7
REPEATER MEMORY

While in VFO enter freq

Press "MON" press "TONE"(8) key
Press "MAIN" so "TONE" appears
on display

Rotate Dial 1 click to "TONE SET"

Press "BAND" key
Press "MAIN" key until
desired freq appears
Press "BAND" key, press PTT
Press "MON" key ½ second
Press "MON" key again to store,
Press PTT

SQUELCH ADJUSTMENT

Press "MON" key then press MONI
switch on left side of radio
Press "MAIN" to set level
Press PTT

----- NOTE-----

IF PROGRAM DOESN'T
WORK, NOTIFY ME OF
SETTINGS TO BE
CORRECTED

KG6RLG at ARRL dot .NET