

YAESU VX-5

SIMPLEX FREQS
select frequency in VFO
press F/W
press "1", press PTT
press F/W 1 second
press F/W to store

TONE ENCODE
press F/W then "1"
rotate dial to TONE
press BAND
rotate dial to TONE SET
press BAND
rotate dial to TONE FREQ
press PTT to save

KEYBOARD LOCK
press F/W then TX/PO

RON GREEN KG6RLG

YAESU VX-5

REPEATER FREQS
select frequency in VFO
press F/W, press "1"
rotate dial to TONE
press "BAND"
rotate dial to TONE SET
press "BAND"
rotate dial to TONE FREQ
press "2", press PTT
press F/W 1 second
press F/W to store

REVERSE
press F/W then MONI
SQUELCH
press F/W then "0"

POWER CHANGE
press tx/po
BATTERY VOLTAGE
press and hold "3"